



## REP-232-3P

### Industrial RS-232 Isolated 3-Wire Repeater Pair

Datasheet Revision 2.7

[SERIALCOMM.COM](http://SERIALCOMM.COM)

#### GENERAL FEATURES:

- Plug-and-Play (hot-pluggable)
- 2500V optical isolation
- Data direction auto-turnaround - no flow control necessary
- Port powered - no external power needed
- Built-in surge and static protection
- 5-year replacement manufacturer's warranty
- CE, FCC, RoHS and REACH certified



#### DESCRIPTION:

The SerialComm REP-232-3P is a pair of industrial grade bi-directional port powered 2500V opto-isolated RS-232 port extenders. The converter pair can extend the data distance of two standard full duplex RS-232C ports up to 4000 ft(1.2km). A built-in data direction auto-turnaround feature automatically enables the wire driver when data is present from the RS-232 port, eliminating the need for software drivers, and making the device fully plug-and-play. The REP-232-3P has a DB9 female connector on the RS-232 serial port, and db-9 male connector on the wire port. A separate terminal block is included with each converter for maximum flexibility. The terminal block plugs into the wire port, providing screw-lug wire terminations for the port. The unit is enclosed in a rugged ABS housing and is powered from the RS-232 data lines; no external power is required.

#### CERTIFICATIONS:



#### APPLICATIONS:





FIGURE 1: EXTENDING RS-232 DATA DISTANCE

#### PINOUT CONFIGURATION: RS-232 SIDE – DB9 FEMALE

SIGNAL	DC D	DTR	DSR	RTS	CTS	TX	RX	GND
PIN #	1	4	6	7	8	2	3	5
FUNCTION	TIED			TIED		TX	RX	GND

#### FEM. DB9




#### WIRE SIDE – DB9 MALE OR TERMINAL BLOCK

SIGNAL	NC	R-	T-	T+	R+
PIN #	1	2	3	4	5
FUNCTION	NC	R-	T-	T+	R+



#### MALE DB9



#### SPECIFICATIONS:

COMMUNICATION	
<b>STANDARDS:</b>	EIA/TIA RS-232C Standard
<b>BAUD RATES:</b>	From 300 bps to 115,200 bps
<b>CONNECTOR TYPES:</b>	RS-232 Side: DB9 Female and Wire Side: either DB9 Male or 5-way Terminal Block
<b>DISTANCE:</b>	RS-232 Side: 16 ft (5m) and Wire Side: up to 4000 ft (1.2km)
ELECTRICAL	
<b>POWER SOURCE:</b>	Port Powered From RS-232 Data Lines
<b>OPTICAL ISOLATION:</b>	2500 V (2500Vrms 1 min, AC)
<b>CURRENT CONSUMPTION:</b>	Less Than 10 mA
<b>STATIC PROTECTION:</b>	15KV Electric Static Discharge (ESD) Protection
<b>SURGE PROTECTION:</b>	600W Surge Protection
MECHANICAL	
<b>HOUSING:</b>	Rugged ABS
<b>WEIGHT:</b>	<b>With Terminal Block:</b> 1.2oz (36 grams) <b>Without Terminal Block:</b> 0.8oz (24 grams)
<b>DIMENSIONS:</b>	<b>With Terminal Block:</b> 3.17" X 1.33" X 0.73" (80.5 mm X 33.8 mm X 18.6 mm) <b>Without Terminal Block:</b> 2.47" X 1.33" X 0.70" (62.8 mm X 33.8 mm X 17.8 mm)
ENVIRONMENTAL	
<b>OPERATING TEMP.:</b>	-40° F to 185° F (-40°C to 85° C)
<b>STORAGE TEMP:</b>	-40° F to 185° F (-40°C to 85° C)
<b>OPERATING HUMIDITY:</b>	5% To 95% - No Condensation
QUALITY	
<b>PRODUCT SAFETY:</b>	CE, FCC, RoHS and REACH Third-party Certified
<b>QUALITY MANAGEMENT</b>	Manufactured and Distributed to ISO 9001:2015 QMS
<b>MEAN TIME BEFORE FAILURE:</b>	301,963 Hours
<b>RELIABILITY:</b>	Low Failure Rate – 99+% Reliability Since Inception
<b>WARRANTY:</b>	5 Year Replacement Warranty

## TROUBLESHOOTING INSTRUCTIONS:

Using one REP-232-3P unit:

1. Check that all connections comply with the connection diagrams.
2. Perform a loop back test on one unit:
  - a) Connect the TX+ to RX+ and TX- to RX- on the wire port.
  - b) Connect the RS-232 port to the PC RS-232 port.
  - c) Running a hyper terminal program on the PC, send ASCII characters to the REP-232-3P converter from one PC port, and check that the characters are received at the same PC port. This tests that the transmit and receive functions of the REP-232-3P unit is working properly.

Using two REP-232-3P units:

1. Check that all connections comply with the connection diagrams.
2. Perform a loop back test on two units:
  - a) Connect the two wire ports per application diagram.
  - b) Connect the two RS-232 ports to two PC RS-232 ports.
  - c) Running hyper terminal programs on both PCs, send ASCII characters to the REP-232-3P converter from one PC port, and check that the characters are received at the 2<sup>nd</sup> PC port. Repeat the test in the opposite direction. This tests that the transmit and receive functions of both REP-232-3P units are working properly.